

CAUTION: Adhesive bonds on contact. Please read entire instructions first.

To install an AAL Spot Anchor:

- Select the best location to mount the anchor by placing the equipment where it will be used. Consider the position of each piece of equipment to be secured, where all the anchors and cables will be located, and the direction of the anchor loops.
- Be certain the mounting surface is completely flat and has no curves. Anchors are best applied when the mounting surface is horizontal. Tip equipment if necessary.
- Clean the gluing surface. If you are applying the anchor to a painted metal surface, a secure bond may be difficult. Remove the paint in advance by lightly sanding.
- Apply a liberal bead of adhesive down the center of the anchor. The adhesive is moisture activated so it may be helpful to lightly blow on the wet adhesive. Use enough adhesive so that when the anchor is mounted, its mounting surface will become completely covered with adhesive.
- Press the anchor against the equipment case without twisting and hold it in place firmly for at least 30 seconds. It is normal for some adhesive to ooze out the sides. Wipe away any excess adhesive with a tissue.
- The adhesive sets in seconds and the anchor cannot be removed or adjusted. Allow several hours to fully set. Maximum bond is achieved after 24 hours.



Note: Some product cases are made with a type of plastic that makes an immediate bond difficult. Follow the same procedures above, but allow the anchor to remain in place without movement (preferably weighted down) for 24 hours. An excellent bond can then be achieved.

CAUTION: Avoid getting adhesive on skin, in eyes or on clothes. Keep out of the reach of children. Use with care.

Thank you for choosing SecurTech