

To install the SecurTech Premium Cable Lock Kit:



- Determine a secure fixture which you can wrap the security cable around or through. Be sure this point is close enough so the cable can reach your device's security slot.
- Suggested secure fixture:
 - A cable hole in the top of the desk (photo 1)
 - The portion of a table leg between the supporting cross bar and the table top
 - An attached Desktop Anchor Point (SecurTech item number DAP)
- Wrap the cable around the secure fixture and pass the lock end of the cable through the loop in the other end of the cable. Pull it all the way through until it is snug.
- Insert the key into the cable's lock cylinder and unlock the lock by rotating the key counter-clockwise (left).
- Carefully insert the locking mechanism into your device's security slot as far as it will go. Turn the key clockwise (right). It should rotate a half-turn and produce a snug fit. Remove the key.
- To unlock, insert the key and rotate it counter-clockwise (left) as far as it will turn. It should rotate a half-turn. Gently pull the locking mechanism out of your device.
- If you have difficulty removing the lock due to a tight fit, you may need to jiggle it gently as you remove it. Partially unscrewing the base of the locking cylinder may assist removal (do this only when it is in the unlocked position).

Thank you for choosing SecurTech.

To secure additional devices:

You can secure multiple devices with a single KLK160 cable. The cable can pass through multiple Scissor Clips and Spot Anchors between the secure fixture and the lock cylinder.



Scissor Clips are sold separately and are used to secure devices that have a standard built-in security slot. The Scissor Clip (left) comes with a Scissor Clip Insert (right).

SecurTech item: USC1



Spot Anchors are sold separately and are used to secure devices that do not have a standard built-in security slot. Spot Anchors are available in multiple shapes and cable lengths.

SecurTech item: AL



The Desktop Anchor Point is sold separately and can be mounted to a wood surface to create a secure fixture where no other adequate anchor point is available.

SecurTech item: DAP

To use the Scissor Clip or Desktop Anchor Point, the KLK160 cable lock will need to be disassembled. Hold the cylinder lock with one hand and unscrew the rough aluminum portion with the other hand. The cylinder lock will come apart into three pieces.

Once the cylinder lock has been separated from the cable, the cable will then pass through the Desktop Anchor Point and/or Scissor Clip(s). You will need to reassemble the cylinder lock to secure the cable.

